
BRIDGE LIFTING GUIDE

HALF-THROUGH TRUSS BRIDGE

NOTE:

DIAGRAM SHOWN FOR GENERAL REFERENCE ONLY SEE BRIDGE DESIGN DRAWINGS FOR ACTUAL BRIDGE SIZE AND MEMBER LAYOUT.

THE METHOD AND SEQUENCE OF LIFTING AND PLACING THE BRIDGE SUPERSTRUCTURE IS THE RESPONSIBILITY OF THE ERECTOR AND IS DEPENDENT UPON SUCH ITEMS AS SITE CONDITIONS ACCESSIBILITY FOUIPMENT, AND MANPOWER



THE BRIDGE STRUCTURES ARE DESIGNED TO BE LIFTED FROM EITHER THE APPROXIMATE 1/4 TO 1/3 POINTS OR FROM THE BEARING LOCATIONS. BRIDGE STRUCTURES ARE NOT DESIGNED FOR LAUNCHING STRESSES.